



NetterVibration



Original Installation and Operating
Instructions for Netter
Electric External Vibrators

June 2016
No. 1572E
Page 1/24

These operating instructions apply to: **Series NEA**
Series NEG



Netter GmbH
www.NetterVibration.com

Germany
Fritz-Ullmann-Straße 9
55252 Mainz-Kastel
Tel. +49 6134 2901-0
info@NetterVibration.de

Poland
Al. W. Korfatego 195/17
40-153 Katowice
Tel. +48 32 2050947
info@NetterVibration.pl

Switzerland
Erlenweg 4
4310 Rheinfelden
Tel. +41 61 8316200
info@NetterVibration.ch

Spain
Errota Kalea 8
20150 Villabona-Guipúzcoa
Tel. +34 943 694 994
info@NetterVibration.es

Serving industry with vibration

Table of Contents

1	GENERAL NOTES	3
2	SAFETY	6
3	TECHNICAL DATA	7
4	DESIGN AND FUNCTION	8
5	TRANSPORT AND STORAGE	9
6	INSTALLATION	10
6.1	Mounting of the vibrator	10
6.2	Electrical connection	11
7	START-UP	14
8	ADJUSTMENT OF UNBALANCES	15
9	TROUBLESHOOTING	18
10	SERVICE / MAINTENANCE	19
11	SPARE PARTS	22
12	ACCESSORIES	23
13	DISPOSAL	24
14	ENCLOSURES	24

Scope of delivery

As a rule, the NEG are delivered with the following components:

- Electric external vibrator (NEG)
- Operating instructions
- Packaging

For changes to the scope of delivery see delivery note.

Check the packaging for possible signs of transport damage.

In the event of damage to the packaging, check that the contents are complete and undamaged. If there is any damage, inform the shipping agent. Compare the scope of the delivery with the delivery note.

1 General Notes

Information on the operating instructions

Use and storage of the operating instructions

Before using the electric external vibrators of the series NEG read this operating manual carefully. It is the basis for any action taken with regard to the NEG and may be used for training purposes. The operating manual should subsequently be stored near the NEG.

Target group

The target group for these operating instructions is qualified technical personnel from the mechanical engineering sector who have a fundamental knowledge of electrics and mechanics.

Installation, commissioning, maintenance, fault elimination and disassembly of the NEG must only be performed by persons who have been instructed in the proper handling of the units.

Persons who have not been instructed accordingly must not carry out any works on the NEG.

Copyright

This documentation is subject to copyright. All rights e.g. for translation, photo-mechanical reproduction, printing or reproduction (e.g. data processing, data carriers and data networks) of this operating manual, or parts thereof, are strictly reserved to **NetterVibration**.

Limitation of liability

All technical information, data and instructions on installation, operation and maintenance in these operating instructions are based on the latest information available at the time of printing and take into account our past experience to the best of our knowledge.








No claims can be derived from the information, illustrations and descriptions in these operating instructions.

The manufacturer does not assume liability for damages resulting from:

- failure to observe the operating instructions
- improper use
- unauthorized repairs
- technical modifications
- use of inadmissible spare parts

Translations are made to the best knowledge. **NetterVibration** does not assume liability for translation errors, even if the translation was made by us or on our behalf. Only the original German version is binding.

The following instruction and warning symbols are used in this operating manual:

	DANGER OF EXPLOSION	indicates a possible explosion which can result in death or personal injury if the instruction is not followed.
	DANGER	indicates a possible danger which can result in death or personal injury if the instruction is not followed.
	WARNING	indicates a possible danger which can result in personal injury, and/or material damage if the instruction is not followed.
	HOT SURFACE	indicates a possible danger which can result in personal injury and/or material damage if the instruction is not followed.
	DISCONNECT POWER SUPPLY	indicates a possible danger which can result in personal injury if the instruction is not followed.
	IMPORTANT	note with especially useful information and tips.
	ENVIRONMENTALLY FRIENDLY DISPOSAL	indicates the obligation of an environmentally friendly disposal.

Information on NEA and NEG

Netter electric external vibrators of the series NEA and NEG comply with the EC machinery directive 2006/42/EC, the electromagnetic compatibility directive 2014/30/EU and the low voltage directive 2014/35/EU.

In particular, the standards DIN EN ISO 12100, DIN EN 60529 and EN 60034-1 have been complied with.

The electric external vibrators of the series NEA and NEG with the housing sizes 50 and 60 are suitable for use in potentially explosive areas of category 3D in the zone 22.

From housing size 100 upwards, the electric external vibrators of the series NEG also comply with directive 94/9/EC for device group II and are suitable for use in potentially explosive areas of category 2D in the zones 21 and 22 (LCIE 07 ATEX 6015 X). In particular, the standards DIN EN 61241-0 and 61241-1 have been complied with.

Special features:

- Adjustable centrifugal force
- All vibrators are impregnated for tropical use by vacuum casting or by trickle impregnation.
- 100% duty cycle
- Degree of protection IP 66 (EN 60529), housing size 50 and 60: degree of protection IP 65
- Insulation class F
- High rate of efficiency due to silicon electrical sheets
- Terminal box integrated in housing foot (housing sizes 101 to 120)
- Smallest mounting dimensions
- Stainless steel end covers
- Sound level measured in the open ≤ 70 dB(A) acc. to IEC
- From housing size 170 upwards, equipped with PTC thermistors by default
- Earthing screw on housing and in terminal box

2 Safety

Intended use:

The vibrators are intended for installation in machines according to the device group and the device category. These machines use vibrations for sieving, loosening, conveying, compacting and separation of bulk materials.

Any other use is considered improper use.

Qualification of the personnel:

Assembly, commissioning, maintenance and repair of the vibrators must be performed only by authorized qualified personnel.

Any handling of the electric vibrators lies within the responsibility of the operator.

Accessories which ensure the correct operation and safety must provide a protection type required for the specific use.



Netter electric external vibrators generate vibrations.


The operator of vibration systems has to protect his employees from actual or potential threats to their health and safety due to vibrations.



Netter GmbH does not assume liability for injury or damage resulting from technical modifications to the product or failure to observe the instructions and warnings in this operating manual.



Live parts can cause severe or even fatal injury.




DISCONNECT
POWER
SUPPLY

When working on the vibrators these must be isolated from the mains supply. To do so please proceed as follows:

1. Switch off vibrator
2. Secure against switching on unintentionally
3. Make sure it is de-energized



The vibrators must not be touched during operation or shortly after being switched off. The surface of the vibrators may become very hot during operation so that there is a risk of burning.



The electric external vibrators are built in accordance with the latest EC directives.

Before using these vibrators in hazardous dusty areas, the operator must ensure that there is no risk of explosion due to the introduction of vibration energy.

The installation and operation of the vibrators is to be carried out in accordance with the ATEX regulations for operation in potentially explosive environments, the requirements of the local electrical engineering associations (e.g. VDE) and the known accident prevention rules.

3 Technical Data

Admissible operating conditions

Mains voltage and frequency:

Mains voltage and mains frequency must comply with the mains voltage and frequency indicated on the type plate.

Series NEA and NEG:

Voltage and frequency see details on type plate.

Power supply by means of:

- fixed voltage and frequency or
- frequency converter

The operation of three-phase vibrators of the series NEG with frequency converters allows rotary speeds of > nominal frequency. If the electric external vibrators are operated with a frequency converter, compliance with the EMV directive has to be ensured.

In zones 21 and 22 the frequency converter may regulate the frequency between 20 Hz and 50 Hz or 20 Hz and 60 Hz (please check max. frequency on type plate) at a constant torque load (linear Volt-Hertz-curve).

Rotary speed ranges:

2-pole 3000 rpm 50 Hz / 3600 rpm 60 Hz

4-pole 1500 rpm 50 Hz / 1800 rpm 60 Hz

6-pole 1000 rpm 50 Hz / 1200 rpm 60 Hz

8-pole 750 rpm 50 Hz / 900 rpm 60 Hz

Admissible ambient temperature:

-20°C to 40°C* or

-20°C to 55°C*

The maximum ambient temperature specified on the type plate must not be exceeded.

These values are valid for operation with an ON-period of 100%.

Cycled or frequency-controlled operation or synchronous operation are subject to specific requirements. These must be clarified with **NetterVibration** for each individual case.

These electric vibrators must not be used in environments with a highly explosive gas atmosphere.

Thermal overload protection:

By default, from housing size 170 upwards with thermistors type PTC 130°C.

For smaller vibrators available as first equipment on request.

If the vibrator is operated in environments containing explosive dust (zone 21 and 22), it is mandatory to connect the PTC-thermistor. This regulation does not apply if the unit is not equipped with a PTC-thermistor.

Sound level:

Depending on type ≤ 70 dB(A)

The sound level is determined to a great extent by the surface upon which the vibrator is mounted (e.g. sheet metal). The sound level will be amplified by non-silenced sheet metal.

*) Higher temperatures are only possible after consultation of and written approval from the application technicians of Netter GmbH.



IM-
PORTANT

Please refer to the type plate for the technical data of your electric external vibrator.

Type plate for sizes 50 and 60

Type designation ⇒
 Rotary speed ⇒
 Nominal voltage ⇒
 Current ⇒
 Phases ⇒
 Serial number ⇒

NetterVibration Germany, 55252 Mainz-Kastel Tel.: +49 6134 2901-0 CE Ex II 3 D tD A22 IP65 T100°C			
Type		Duty	%
n	min ⁻¹	Fc	N
U	V	f	Hz
I	A	P	kW
Ph		Ins. Cl.	
No.		Year	Prot.

⇒ Duty cycle
 ⇒ Centrifugal force
 ⇒ Nominal frequency
 ⇒ Power
 ⇒ Insulation class
 ⇒ Degree of protection

Type plate from size 100 upwards

Type designation ⇒
 Nominal voltage ⇒
 Current ⇒
 Phases Capacity ⇒
 Power factor ⇒
 Year of manufacturing ⇒
 Serial number ⇒

NetterVibration Germany, 55252 Mainz-Kastel, Tel.: +49 6134 2901-0 0722 Ex II 2 D tD A21 IP66 T 100 °C			
Type	LCIE 07	Duty	100 %
U	ATEX 6015 X	Fc	N
I	A	n	min ⁻¹ f Hz
Ph	Cap. µF	P _{in}	kW
cos φ		P _{out}	kW
Year		Ins. Cl. F	Prot. IP66
No.		Max. Amb.	40 °C

MAY BE USED WITH PWM INVERTER - CT-20 HZ TO BASE FREQUENCY
 CAUTION: USE SUPPLY WIRE SUITABLE FOR 105 °C

⇒ Temperature class T (D)
 ⇒ Duty cycle
 ⇒ Centrifugal force
 ⇒ Rotary speed Nom. frequency
 ⇒ Power input
 ⇒ Power output
 ⇒ Insulation class Protection
 ⇒ Max. ambient temperature

For detailed technical data of vibrators please refer to the tables in the middle section of these operating instructions (removable).

4 Design and Function

- **The electric motor** for the series NEA is a single-phase asynchronous motor (capacitor included on the supply cable or in the capacitor box).
The electric motor for the series NEG is a three-phase asynchronous motor.
- To achieve a high rate of efficiency at a low temperature of the motor, the stators of the asynchronous motors are made of electric sheet steel with a low dissipation factor.
- The vacuum resin cast stators are a particular quality feature. The dried resin bonds housing and stator together to form an inseparable unit, which is robust and tropical proof. From housing size 140 upwards the stators are trickle impregnated. With this method the spaces between the individual windings are completely filled and a vibration resistant seating of the complete unit is achieved.
- Motor protection by incorporated PTC-thermistor 130°C; by default from size 170 upwards (DIN 44081 and DIN 44082).
- Protection by housing “tD” for use in areas with explosive dust atmosphere.
- **The motor shaft** is made of heat-treated round alloy steel.
- **The special bearings** are over-dimensioned for excessive loads and high speeds.
- All units are suitable **for speed regulation** with frequency converters.
- **The housing** of sizes 50 to 140 and 160 are made of an aluminum alloy.
- **The housing** of sizes 150 and 170 to 210 are made of high-tensile nodular cast iron.
- Due to powder coating **the paint finish** is highly weather resistant as well as resistant against abrasion, impacts and a wide variety of chemicals. Colour: traffic black.
- **The unbalance masses** are adjustable as follows:
 Type XS continuously adjustable
 Type XM in 10% steps
 Type XLs in 20° steps
 Type XL by removable discs
- **The covers of the unbalances** are made of stainless high-grade steel.

5 Transport and Storage



IM-
PORTANT

Check the packaging for possible shipping damage.

If damage to the packaging is found check the content for completeness and possible damage. In case of damage inform the forwarding agent.

The units are packed ready for installation. The type plate is attached to the vibrator. If not specified differently the vibrator is delivered with an unbalance setting of 100%.

When transporting the vibrator make sure to avoid hard impacts or vibrations which could damage the bearings.

The unit should be stored in a clean, dry environment.

If the vibrator needs to be in storage for a longer period of time (2 years max.), the temperature in the store must not fall below -15°C or above +60°C and the relative air humidity must not exceed 60%.



EXPLO-
SION
HAZARD

If the vibrator is operated in areas with explosive dust (zones 21 and 22), maintenance by **NetterVibration** is compulsory in case the unit was kept on stock for more than a year.



WARNING

The transport eyes must solely be used to lift the vibrator.

If the vibrator is fitted with two transport eyes, both of these should be used for lifting. The lifting angle must not exceed 45°.



6 Installation



**IM-
PORTANT**

The installation of the vibrators must only be carried out by authorized, qualified personnel.

The qualified personnel must use only tools, which are suitable for the application.



**IM-
PORTANT**

During installation please comply strictly with the safety regulations in chapter 2 and the accident prevention rules!

Installation of the system must be performed in compliance with the local, applicable regulations (e.g. VDE-regulations).

6.1 Mounting of the vibrator


Netter electric external vibrators can be operated in any position.

During installation the following notes must be strictly observed:



WARNING

The mounting surfaces must be absolutely level ($\pm 0.1\text{mm}$ flatness fault), so that the feet of the vibrators have full area contact and to avoid warping of the housing when tightening the fastening screws. The surfaces should also be free of any paint residues and weld penetrations. Tensions in the housing can cause mechanical and/or electrical damage.



For safe fastening we recommend the use of Netter NBS screw connections consisting of screw, special lock washer and, if necessary, nut.

The vibrators can also be fastened with fastening screws of quality 8.8 (DIN 931 or 933). These must be locked with qualified locking devices and retightened at regular intervals (normally every month).



WARNING

The tightening torques can be taken from the following table. Higher tightening torques may cause fracture of screws or tearing of threads. Inadequate screw connections may cause loosening of vibrators by vibration. This can cause damage to persons and material!



Recommended tightening torques for fastening screws

(screws as supplied, without additional lubrication):

Type of screw	M6	M8	M10	M12	M14	M16	M18	M20	M24
Property class 8.8 [Nm]	10	23	48	80	130	190	270	380	650
Stainless steel screws [Nm]	8	20	40	67	112	-	-	-	-


Use a torque wrench and tighten the screws in a crosswise pattern.



In critical installation situations use an additional security device including a steel rope, e.g. NSE.

Adjust the safety rope to the shortest possible length by means of the wire rope clips.

The safety rope must be tensioned at all times!



6.2 Electrical connection



**IM-
PORTANT**

The electrical installation of the vibrators must be performed only by authorized, qualified personnel.

The qualified personnel must use only insulated tools, which are suitable for the application.




**IM-
PORTANT**

The mains voltage and the mains frequency have to correspond to the nominal voltage and frequency indicated on the type plate.

A voltage tolerance of $\pm 5\%$ or a frequency tolerance of $\pm 2\%$ are admissible.

Connection examples NEG

The vibrator circuitry must be connected in accordance with its type plate as follows:





Thermistor

The green-yellow conductor is the earth conductor and must only be used for connection to the earth terminal.



More terminal plans (e.g. for special voltages) on request.

Series NEG / alternating current 3-phase


Lower voltage



Higher voltage



Connection example NEA



Capacitor included on the cable



Cable with capacitor box



**IM-
PORTANT**

Each vibrator must be connected to a suitable overload protection. For dual operation, the motor protection switches must be interlocked to ensure that in case one motor breaks down, the current supply is stopped from both motors simultaneously. This is to prevent uncontrolled vibrations, which could cause damage to the equipment.



**EXPLO-
SION
HAZARD**

In zones 21 and 22 the motor protection switches have to be approved for applications in potentially explosive areas.



**EXPLO-
SION
HAZARD**

In zones 21 and 22 an additional external earthing is to be made via the earthing connection of the housing base.




**EXPLO-
SION
HAZARD**

Thermic overload protection:


Standard equipment with PTC-thermistor 130°C from housing size 170 upwards.
For smaller units available as first equipment on request.

If the vibrator is operated in environments containing explosive dust (zone 21 and 22), it is mandatory to connect the PTC-thermistor. This regulation does not apply if the unit is not equipped with a PTC-thermistor.





The connection of the vibrators has to be made only by using the appropriate flexible cables. The conductors in the supply cable for the connection of the vibrator to the mains supply must be temperature-resistant and have a sufficient large cross-section matched to the length of the cable used. The max. surface temperature indicated on the type plate determines the degree of temperature resistance of the cable.



**IM-
PORTANT**

When selecting the connecting cables, please consider the mechanical demands on the cables due to vibration.

The recommended cable types for power supply operation with 400 V in non-explosive atmosphere: rubber hose line H07 RN-F or Ölflex cable 110 CY. In case of other voltages or other environmental conditions the cables have to be adapted and designed accordingly.



**EXPLO-
SION
HAZARD**

The terminal box cover must not be opened in a potentially explosive area or with voltage applied. If the terminal box cover or unbalance covers are open, check the condition and correct positioning of the seals. Damaged seals must be replaced immediately.

WARNUNG **WARNUNG**

**Nicht öffnen in explosions-
fähiger Atmosphäre.**

**Do not open in an
explosive atmosphere**

Cable temperature
near the cable
gland: 120°C



DANGER

The electric lines have to be laid with care. It has to be avoided that the cables can be chafed through by vibrating parts.

The condition of the electric lines incl. plugs has to be checked at regular intervals (normally every six months). Defects which are discovered have to be eliminated immediately. Protect the cable against high temperatures, lubricants and sharp edges.



**IM-
PORTANT**

The ends of the leads must be fitted with isolated cable clips, to prevent the strands from splaying. The maximum cable clip sizes are shown in the following list:


Set screw M4 max. AWG 18
Set screw M5 max. AWG 16
Set screw M6 max. AWG 12
Set screw M8 max. AWG 12



DANGER

Tighten junction plate nuts using the prescribed torque. Be careful not to forget the safety washer between the ring and the nut and to reinsert the vibration-damping insert.

M 4 \Rightarrow 1.2 Nm
M 5 \Rightarrow 2.0 Nm
M 6 \Rightarrow 3.0 Nm
M 8 \Rightarrow 6.5 Nm
M 10 \Rightarrow 13.5 Nm



7 Start-up

During start-up of the vibrators the rules and regulations of local associations for electrical engineering (e.g. VDE) and the applicable accident prevention rules must be observed.



**IM-
PORTANT**

The vibrators must always be switched on and off at a main switch.

If the electric external vibrators are operated with a frequency converter, compliance with the EMC directive must be ensured.

If the rotary speed is regulated by means of a frequency converter, pay attention to the maximum frequency indicated on the type plate.



WARNING

The vibrators must not be operated without the cover for the unbalances in place! The rotating unbalances cause a risk of injury!



In zones 21 and 22 the frequency converter may regulate the frequency between 20 Hz and 50 Hz or 20 Hz and 60 Hz (please check max. frequency on type plate) at a constant torque load (linear Volt-Hertz-curve).



**EXPLO-
SION
HAZARD**

Explosion-protected vibrators must only be used in atmospheres which will not damage the material of the device.

The terminal box cover must not be opened in a potentially explosive area or when voltage is applied.

The complementary regulations and instructions for hazardous areas must be complied with.



DANGER

During initial start-up the current consumption must be measured individually in all three phases and must comply with the data on the type plate.



WARNING

The vibrators have to be adapted to your application by adjusting the unbalances. You can directly influence vibration amplitude, centrifugal force and current consumption, see chapter 8 „Adjustment of Unbalances“.

Retightening:

Screw connections must be checked and, if necessary, retightened after 1 hour of operation (after initial start-up) and then at regular intervals (as a rule, once per month).

8 Adjustment of Unbalances



**IM-
PORTANT**

All vibrators of the series NEA and NEG offer the possibility of adjusting the unbalances.


Unless otherwise specified by you, the units will be shipped with the default setting (100%).

By adjusting the unbalances you can directly influence the vibration amplitude, centrifugal force and current consumption.



WARNUNG

On all units the unbalances must only be adjusted symmetrically mirrored!



The tables below show the type of unbalance and the number of unbalances per vibrator at the default setting of 100%.

Type	Unbalance		
	Type	Number	
		50 Hz	60 Hz
NEA 504	XL	8	8
NEA 5020	XL	8	8
NEA 5050	XL	18	18

NEA 5060	XLs	4	4
----------	-----	---	---

NEA 50120	XM	4	4
NEA 50200	XM	4	4
NEA 50300	XM	4	4
NEA 50550	XM	4	4
NEA 50770	XM	4	4
NEA 2530	XM	4	4
NEA 2570	XM	4	4
NEA 25210	XS	4	4
NEA 25420	XS	4	4
NEA 25540	XS	4	4
NEA 25700	XS	4	4

Type	Unbalance		
	Type	Number	
		50 Hz	60 Hz
NEG 5020	XL	8	8
NEG 5050	XL	18	18

NEG 5060	XLs	4	4
----------	-----	---	---

NEG 50120	XM	4	4
NEG 50200	XM	4	4
NEG 50300	XM	4	4
NEG 50550	XM	4	4
NEG 50770	XM	4	4
NEG 50980	XM	4	4
NEG 501140	XM	4	4

NEG 501540	XLs	12	8
NEG 501800	XLs	14	10
NEG 502020	XLs	16	10
NEG 502270	XLs	18	12
NEG 503400	XLs	12	8
NEG 503820	XLs	14	10

NEG 506220	XS	4	4
NEG 508830	XS	4	4

Type	Unbalance		
	Type	Number	
		50 Hz	60 Hz
NEG 2530	XM	4	4
NEG 2570	XM	4	4

NEG 25210	XS	4	4
NEG 25420	XS	4	4
NEG 25540	XS	4	4
NEG 25700	XS	4	4
NEG 25930	XS	4	4
NEG 251410	XS	4	4
NEG 251800	XS	4	4
NEG 252060	XS	4	4
NEG 252370	XS	4	4
NEG 253050	XS	4	4
NEG 253720	XS	4	4
NEG 254310	XS	4	4
NEG 254900	XS	4	4
NEG 256460	XS	4	4
NEG 258040	XS	4	4
NEG 258260	XS	4	4
NEG 2511210	XS	4	4
NEG 2513850	XS	4	4

NEG 1630	XM	4	4
----------	----	---	---

NEG 1690	XS	4	4
NEG 16190	XS	4	4
NEG 16310	XS	4	4
NEG 16410	XS	4	4
NEG 16500	XS	4	4
NEG 16810	XS	4	4
NEG 161130	XS	4	4
NEG 161420	XS	4	4
NEG 161610	XS	4	4
NEG 162110	XS	4	4
NEG 162550	XS	4	4
NEG 163030	XS	4	4
NEG 163820	XS	4	4
NEG 164700	XS	4	4
NEG 165190	XS	4	4
NEG 166270	XS	4	4
NEG 166670	XS	4	4
NEG 167890	XS	4	4
NEG 168500	XS	4	4
NEG 169510	XS	4	4
NEG 1612060	XS	4	4
NEG 1613890	XS	4	4
NEG 1617000	XS	4	4

Type	Unbalance		
	Type	Number	
		50 Hz	60 Hz
NEG 12100	XS	4	4
NEG 12180	XS	4	4
NEG 12230	XS	4	4
NEG 12460	XS	4	4
NEG 12640	XS	4	4
NEG 12900	XS	4	4
NEG 121430	XS	4	4
NEG 122150	XS	4	4
NEG 122640	XS	4	4
NEG 122920	XS	4	4
NEG 123530	XS	4	4
NEG 124440	XS	4	4
NEG 127640	XS	4	4
NEG 128520	XS	4	4
NEG 1211070	XS	4	4
NEG 1213160	XS	4	4
NEG 1217670	XS	4	4

Procedure:

- Switch off vibrator, secure it against unintentional switching on and make sure that no voltage is applied.
- Loosen both covers for the unbalances.
- Slacken the locking nuts or locking screws.
- Adjust the discs or cast iron unbalances as required.
- Tighten the locking nuts or locking screws.
- Reinstall the covers for the unbalances.

Unbalance discs type XL

The centrifugal force is adjustable by means of the unbalance discs of type XL in the following steps:

		Centrifugal force in %										
Number of unbalance discs per side	15	100										
	14	93										
	13	87	100									
	12	80	92									
	11	73	85	100								
	10	67	77	91	100							
	9	60	69	82	90	100						
	8	53	62	73	80	89	100					
	7	47	54	64	70	78	88	100				
	6	40	46	55	60	67	75	86	100			
	5	33	38	45	50	56	63	71	83	100		
	4	27	31	36	40	44	50	57	67	80	100	
	3	20	23	27	30	33	38	43	50	60	75	
	2	13	15	18	20	22	25	29	33	40	50	
	1	7	8	9	10	11	13	14	17	20	25	
		30	26	22	20	18	16	14	12	10	8	
Default number of unbalance discs per vibrator												



There are 2 possibilities to adjust the unbalances:

1. **Fine setting:** The unbalance is adjusted by removing one disc per side. All centrifugal force values in % specified in the table can be adjusted.

The removed discs must be replaced by compensation washers (available from Netter) of identical thickness and identical inner diameter.

Example:

The vibrator of type NEG 25210 / 50Hz with a standard 100% centrifugal force setting has 22 unbalance discs (11 per side).

If a centrifugal force value of 73% is required, the vibrator is mounted with 16 unbalance discs (8 per side). The removed unbalance discs must be replaced by compensation washers of the same thickness and the same inner diameter.



1. **Coarse setting:** The unbalance is adjusted by turning one disc per side by 180° on the shaft. Twice the number of discs turned by 180° becomes ineffective.

Example:

The vibrator type NEG 25210 / 50Hz with the centrifugal force default setting of 100% has 22 unbalance discs (11 per side).

If a centrifugal force value of 27% is required, 8 unbalance discs (4 per side) are turned by 180°. The 3 unbalance discs per side indicated in the table remain effective. The inertia of all discs remains unchanged.



Unbalance discs type XLs

The unbalance setting of the unbalance discs of type XLs is made via the scale disc.

The centrifugal force is adjusted by turning the outer unbalance discs and adjusting them to the pitch lines on the scale disc.



Discs	4, 8, 12, 16	10	14	18	NEG 5060 4 discs
Setting	Centrif. force in %	Centrif. force in %	Centrif. force in %	Centrif. force in %	Centrif. force in %
0°	100	100	100	100	100
20°	99	99	99	99	97
40°	94	94	94	94	88
60°	87	87	87	87	75
80°	76	78	77	77	59
100°	64	66	65	65	41
120°	50	53	52	51	25
140°	34	29	37	36	12
160°	17	26	22	21	3
180°	0	20	14	11	0

Unbalance discs type XM

The unbalance setting of the unbalance discs type XM is made via the scale of the fixed unbalance disc. The centrifugal force is set by turning the outer unbalance disc and by adjusting to the scale division lines. The adjustment can be made in 10% steps.



Recommended average tightening torques for nuts

Nut type	M13 x 1	M15 x 1	M20 x 1	M25 x 1.5	M30 x 1.5	M45 x 1.5
Tightening torque [Nm]	30	50	100	170	340	500

Unbalance discs type XS

The unbalance setting of the unbalance discs type XS is made via the scale of the fixed disc.

The centrifugal force is infinitely adjusted by turning the outer unbalance discs and adjusting them to the scale lines on the scale disc. After adjusting the unbalances, the nuts or screws must be retightened with the specified tightening torque.

With unbalance discs of type XS the centrifugal force can be adjusted according to the following table:



Setting	Centrif. force in %
0°	100
15°	98.5
30°	97
45°	92
60°	87
75°	78.5
90°	70

Setting	Centrif. force in %
105°	60
120°	50
135°	37.5
150°	25
165°	12.5
180°	0

Screw type	M6	M8	M10	M12	M14	M16	M18	M20	M24
8.8 Tightening torque [Nm]	10	23	48	80	130	190	270	380	650
12.9 Tightening torque [Nm]	-	39	79	135	218	314	-	628	-

For screw types M8 to M14 strength class 12.9 is used by default.

9 Troubleshooting



**IM-
PORTANT**

Faults on vibrators must only be repaired by authorized, qualified personnel. The qualified personnel must use only insulated tools, which are suitable for the application.

Fault	Possible cause	Troubleshooting	Remedy
Vibrator does not start or runs with too low speed	Phase interruption	Check fuse and connecting cable	Replace fuse or connecting cable
	Mains voltage too low	Check mains voltage and cable cross-section	Correct mains voltage, replace cable
Vibrator speed drops under load	Wiring fault	Check with terminal plan	
	Insufficient contact on a connecting terminal	Check connection in terminal box	Tighten terminal nuts
	Phase interruption	Check fuse and connecting cable	Replace fuse or connecting cable
	Incorrectly dimensioned connecting cable	Check cable-cross section	Replace the cable
	Overload	Check setting of unbalances	Reduce the unbalance
	Mains voltage too low	Check mains voltage and cable cross-section	Correct mains voltage, replace cable
One phase without current	Phase interruption	Check the connecting cable	Replace the cable
Excessive heating of stator winding	Wiring fault	Check with terminal plan	
	Overload		
	Mains voltage too low	Check mains voltage and cable cross-section	Correct mains voltage, replace cable
Vibrator humming	Phase interruption	Check fuse, mains voltage and connecting cable	Correct mains voltage, replace fuse or cable
	Turn-to-turn fault in the stator winding	Replace the vibrator	
Circuit breaker fails when switched on	Phase interruption	Check fuse and connecting cable	Replace fuse or cable
	Overload	Check setting of unbalances	Reduce the unbalance
	Short circuit in winding	Replace the vibrator	
High current consumption	Natural resonance range of vibration system	Check the current consumption	Stiffen the device
	Impacts	Check the current consumption	Reduce the power of the vibrator
		Fastening loose	Tighten the screws
Bearings overheating	Too much grease in bearings	Fill in correct quantity of grease Klueber Staburags NBU 8 EP.	
	No grease in bearing	Fill in correct quantity of grease Klueber Staburags NBU 8 EP.	
	Foreign body in bearing	Clean bearing, replace if necessary.	

10 Service / Maintenance



**DISCON-
NECT
POWER
SUPPLY**

When working on the vibrator it must be isolated from the mains supply. To do so please proceed as follows:

1. Switch off the vibrator
2. Secure it against switching on
3. Make sure it is de-energized



WARNING

The following maintenance work has to be carried out at regular intervals by authorized and specialized staff with good knowledge of the standard EN 61241-17 (zones 21 and 22):

- a) Checking of the screwed connections
- b) Checking of the ball and roller bearings
- c) Relubricating of roller bearings
- d) Checking of operating hours (service life of bearings)
- e) Checking of cable supply line
- f) Replacement of O-rings and plastic seals every two years

Other maintenance and repair work are to be carried out by *Netter* Vibration exclusively.

Authorized and specialized staff is allowed to perform the following work on the vibrators:

The adjustment of the unbalance discs incl. removal of the unbalance covers.

The electric connection incl. removal of the terminal block cover.

Please observe the safety instructions in chapter 2 when service on the unit is done.



WARNING

Retightening:

Screw connections must be checked and, if necessary, retightened after 1 hour of operation (after initial start-up) and then at regular intervals (normally every month). Pay attention to the specified torque (see chapter 6.1).

Lubrication

Vibrators up to housing size 120 are equipped with ball bearings. These are life-time lubricated (permanent lubrication).

From housing size 130 upwards the units are fitted with roller bearings. These are lubricated with grease of type KLUEBER Staburags NBU 8 EP. This grease has the advantage that the bearings are lubricated for a period of at least 5000 operating hours (up to 3000 rpm). After this time the grease in the bearings must be completely renewed.

Vibrators with speeds exceeding 3000 rpm must be lubricated regularly in intervals of approx. 1000 operating hours.

Under severe operating conditions the lubrication intervals must be considerably shorter.

Service life of ball respectively roller bearings

If the vibrator is used in potentially explosive dust atmosphere, the operator has to control the condition of the bearings and the operating time of the complete unit. Vibrators with defective bearings or with bearings which have reached the end of service life have to be sent to **Netter-Vibration** for exchange immediately.



The condition of the ball and roller bearings must be regularly checked.
The replacement of damaged bearings or bearings which have reached the end of their service life must be made by **Netter Vibration**.

Grease quantity for lubrication and when replacing bearings and bearing life

Type	Grease quantity [g]	Bearing lifetime 50 Hz [h]	Bearing lifetime 60 Hz [h]
NEA 504	Perm. lubrication	> 100.000	> 100.000
NEA 5020	Perm. lubrication	92.118	22.745
NEA 5050	Perm. lubrication	8.087	2.236
NEA 5060	Perm. lubrication	> 100.000	5.044
NEA 50120	Perm. lubrication	18.075	18.075
NEA 50200	Perm. lubrication	3.363	2.572
NEA 50300	Perm. lubrication	4.003	3.588
NEA 50550	Perm. lubrication	4.148	4.219
NEA 50770	Perm. lubrication	7.509	6.257

NEA 2530	Perm. lubrication	> 100.000	> 100.000
NEA 2570	Perm. lubrication	> 100.000	> 100.000
NEA 25210	Perm. lubrication	23.406	19.200
NEA 25420	Perm. lubrication	15.135	12.635
NEA 25540	Perm. lubrication	6.266	4.224
NEA 25700	Perm. lubrication	19.477	16.231

NEG 5020	Perm. lubrication	92.118	22.745
NEG 5050	Perm. lubrication	8.087	2.236
NEG 5060	Perm. lubrication	> 100.000	5.044
NEG 50120	Perm. lubrication	18.075	18.075
NEG 50200	Perm. lubrication	3.363	2.572
NEG 50300	Perm. lubrication	4.003	3.588
NEG 50550	Perm. lubrication	4.148	4.219
NEG 50770	Perm. lubrication	7.509	6.257
NEG 50980	9	5.062	4.833
NEG 501140	9	3.029	2.298
NEG 501540	16	4.038	3.856
NEG 501800	16	2.416	1.833
NEG 502020	30	7.070	8.372
NEG 502270	30	4.775	4.558
NEG 503400	40	8.672	10.267
NEG 503820	40	5.856	5.591
NEG 506220	120	5.743	4.636
NEG 508830	150	9.029	2.790

NEG 2530	Perm. lubrication	> 100.000	> 100.000
NEG 2570	Perm. lubrication	> 100.000	> 100.000
NEG 25210	Perm. lubrication	23.406	19.200
NEG 25420	Perm. lubrication	15.135	12.635
NEG 25540	Perm. lubrication	6.266	4.224
NEG 25700	Perm. lubrication	19.477	16.231
NEG 25930	9	12.103	10.190
NEG 251410	16	10.870	8.330
NEG 251800	30	22.231	20.009
NEG 252060	30	14.300	12.300
NEG 252370	35	16.159	13.032
NEG 253050	35	7.100	5.900

Type	Grease quantity [g]	Bearing lifetime 50 Hz [h]	Bearing lifetime 60 Hz [h]
NEG 253720	40	12.228	11.086
NEG 254310	40	8.200	7.300
NEG 254900	80	9.930	8.648
NEG 256460	120	10.478	8.451
NEG 258040	150	9.029	7.575
NEG 258260	180	11.460	7.881
NEG 2511210	260	10.576	8.718
NEG 2513850	300	9.000	6.200

NEG 1630	Perm. lubrication	> 100.000	> 100.000
NEG 1690	Perm. lubrication	> 100.000	> 100.000
NEG 16190	Perm. lubrication	> 100.000	72.171
NEG 16310	Perm. lubrication	> 100.000	> 100.000
NEG 16410	9	> 100.000	> 100.000
NEG 16500	9	> 100.000	39.516
NEG 16810	Perm. lubrication	> 100.000	60.144
NEG 161130	Perm. lubrication	54.020	42.632
NEG 161420	Perm. lubrication	25.100	20.000
NEG 161610	30	29.165	29.270
NEG 162110	30	11.800	10.400
NEG 162550	32	17.701	12.292
NEG 163030	32	41.500	30.500
NEG 163820	60	13.073	10.842
NEG 164700	80	18.364	15.425
NEG 165190	100	19.206	15.157
NEG 166270	120	15.786	13.144
NEG 166670	120	13.767	14.000
NEG 167890	150	14.431	12.276
NEG 168500	150	11.266	9.379
NEG 169510	180	10.728	10.972
NEG 1612060	260	11.000	11.800
NEG 1613890	300	13.327	11.510
NEG 1617000	360	11.273	10.404

NEG 12100	Perm. lubrication	> 100.000	> 100.000
NEG 12180	Perm. lubrication	> 100.000	> 100.000
NEG 12230	9	> 100.000	> 100.000
NEG 12460	Perm. lubrication	> 100.000	> 100.000
NEG 12640	Perm. lubrication	> 100.000	> 100.000
NEG 12900	30	> 100.000	65.414
NEG 121430	32	> 100.000	39.702
NEG 122150	60	> 100.000	29.320
NEG 122640	80	> 100.000	41.200
NEG 122920	100	> 100.000	43.076
NEG 123530	120	> 100.000	35.405
NEG 124440	150	> 100.000	32.368
NEG 127640	180	29.652	10.982
NEG 128520	260	52.762	18.667
NEG 1211070	300	37.822	15.233
NEG 1213160	360	35.257	12.684
NEG 1217670	400	22.520	9.347


Recommended tightening torques for screws (item 12 and item 22)

Type of screw	M6	M8	M10	M12	M14	M16	M18	M20	M24
8.8 Tightening torque [Nm]	10	23	48	80	130	190	270	380	650
12.9 Tightening torque [Nm]	-	39	79	135	218	314	-	628	-

Recommended tightening torques for nuts (item 25)

Nuts	M13x1	M15x1	M20x1	M25x1.5	M30x2	M45x1.5
Nm	30	50	100	170	340	500

Procedure to lubricate and replace bearings:



1. Switch off the vibrator, secure it reliably against switching on and make sure that it is dead.
2. Unscrew socket head cap screws (29) and remove covers (27) from the unbalances.
3. Disassembling the unbalances:

- Unbalances type XL, type XLs and type XM (15)

Screw a long screw with identical thread into a threaded bore for the fastening screws (29) of the cover for the unbalance. Place a chisel between unbalance discs and this screw. Loosen locking nut (25) (Fig. 1). The unbalances can be pulled off after unscrewing locking nut (25).

- Unbalances of type XS (15) (Fig. 2)

The unbalances can be pulled off after removing the circlip (23) and loosening the clamping screws (22).

4. Removing bearings (8):

- Up to housing size 120 remove circlip (5).
- From housing size 130 unscrew socket head cap screws (12) and disassemble flange (10). Remove circlip (5) from flange (10).

5. Replace both bearings (8) or clean off all old grease (e.g. with gasoline) and fill evenly with the specified quantity (table) of new grease (Klueber Staburags NBU 8 EP).

6. Assembly is performed in reverse order.

Tighten locking nuts (25) and socket head cap screws (12, 22) with the specified tightening torque.



Figure 1




Figure 2


11 Spare Parts

When ordering spare parts you should always provide the following details:

1. Type of unit
2. Description and position of the spare part
3. Required quantity



Example NEG 50200



Example NEG 25210

12 Accessories

The following accessories are available for electric external vibrators of the series NEA and NEG:

Description	Remark
Compensation washers	Compensation for removed unbalance discs
CC-unbalances	Two pre-adjusted working torques can be operated when changing the direction of rotation.
Fastening sets NBS	for secure fastening of electric external vibrators
Frequency converters	for frequency-regulated operation
Brake additives	enable a quicker braking of the vibrators
Special designs	Electric external vibrators are also available in special designs, e.g. for special voltages or for the use in explosive atmospheres. Information on request.
PTC thermistor	PTC 120°C thermistor for safe operation of the vibrators

Other electrical accessories on request.

13 Disposal

Depending on the material, the parts and packaging must be disposed of in an environmentally compatible way.

Material specifications:

	NEA	NEG housing types I, II and III	NEG housing type IV
Stainless steel	Cover for unbalances	Cover for unbalances	
Stahl	Rotor, unbalance, flange, bearings, screws, washers, nuts	Housing sizes 140 and 160, rotor, unbalance, flange, bearings, screws, washers, nuts	Rotor, unbalance, flange, bearings, screws, washers, nuts
Aluminum	Housing, type plate	Housing, type plate, terminal box cover	Housing sizes 150 and 170 to 210, cover for unbalances, type plate, terminal box cover
PTFE, PU, VITON	Seals, terminal box block	Seals, terminal box block	Seals, terminal box block
Copper with resin	Winding	Winding	Winding



**ENVIRONMENTALLY
FRIENDLY
DISPOSAL**

All units can be disposed of through Netter GmbH.
The valid disposal prices are available on request.

14 Enclosures

Enclosure(s):

Declaration of Incorporation



IMPORTANT

**Further information available on request:
Leaflet no. 8 (Netter Electric External
Vibrators), and more.**