

**1E**

## Oil Pressure Switch On-Vehicle Inspection

- 1) Disconnect oil pressure switch lead wire (1).
- 2) Check for continuity between oil pressure switch terminal (2) and cylinder block (3) as shown.  
If check result is not as specified, replace oil pressure switch (4).

### Oil pressure sensor specification

**During engine running: No continuity**

**At engine stop: Continuity**

