

TOP

NEXT

MANUAL LIST

1/2

Manual Group	Manual Part Name	Language	Manual Part Number
(1)	SN413 Service Manual	E	99500-81A02-01E
		F	99500-81A00-01F
		G	99500-81A00-01G
		S	99500-81A00-01S
(2)	SN413 Wiring Diagram Manual	E, F, G, S	99512-81A00-015
(3)	SN413 Supplementary Service Manual	E	99501-81A00-01E
		F	99501-81A00-01F
		G	99501-81A00-01G
		S	99501-81A00-01S
(4)	Jimny (SN413) Service Manual	E	99500-81A10-01E
		F	99500-81A10-01F
		G	99500-81A10-01G
		S	99500-81A10-01S
(5)	Jimny (SN415D) Supplementary Service Manual	E	99501-84A00-01E
		F	99501-84A00-01F
		G	99501-84A00-01G
		S	99501-84A00-01S
(6)	Jimny (SN413 / SN415D) Wiring Diagram Manual	E, F, G, S	99512-81A30-015
(7)	Jimny (SN413 / SN415D) Supplementary Service Manual	E	99501-81A10-01E
		F	99501-81A10-01F
		G	99501-81A10-01G
		S	99501-81A10-01S
(8)	Jimny (SN413 / SN415D) Wiring Diagram Manual	E, F, G, S	99512-81A40-015

E English **F** French **G** German **S** Spanish

HOW TO FIND APPLICABLE MANUALS

[TOP](#)[BACK](#)

MANUAL LIST

2/2

Manual Group	Manual Part Name	Language	Manual Part Number
(9)	Jimny (SN413 / SN415D) Supplementary Service Manual	E	99501-81A20-01E
		F	99501-81A20-01F
		G	99501-81A20-01G
		S	99501-81A20-01S
(10)	Jimny (SN413 / SN415D) Wiring Diagram Manual	E, F, G, S	99512-81A50-015

[E](#) English[F](#) French[G](#) German[S](#) Spanish**HOW TO FIND APPLICABLE MANUALS**