


Fuses in Main Fuse Box (Petrol Model)



No.	Fuse	Protected circuit
43	80 A	All electric circuit
		Battery
		Generator
44	50 A	Individual circuit fuse box No.2 (In J/B)
45	50 A	Individual circuit fuse box No.2 (In J/B)
46	80 A	Individual circuit fuse box No.1
47	80 A	Individual circuit fuse box No.1